




LVK / LVK-C


Installation notes
Montageanleitung
Notice de montage

Manual de Montage
Manuale d'montaje
Montagehandleiding


GB	English	3
DE	Deutsch	5
FR	Français	7
ES	Español	9
IT	Italiano	11
NL	Nederlands	13

TYPE	LVK-5 / LVK-C-5 1.5-6	LVK-5 1,5-16	LVK-5 6-25	LVK-4 16-50	LVK-4 25-95	LVK-4 25-150	LVK-4 95-300
A	120	210	270	360	390	480	600
B	80	140	180	240	260	320	400
C	40	70	90	120	130	160	200


All dimensions in mm. Subject to technical changes.




4.




5.



6.



7.



8.



Your local partner, wherever you are



Contact us

Scan the QR code or click the link to go to our website for country contact details.

HellermannTyton.com/company/worldwide